

KENDALL HOWARD ®

Assembly Instructions

Training Table CPU Holders (SFF & Desktop)

Part Numbers: 5500-3-100-04, 5500-3-100-08




Address: 10152 Liberty Lane
Chisago City, Minnesota, 55013
United States of America

Phone: 651-213-1333
Fax: 800-418-6897

www.kendallhoward.com

Tools Needed:




Screwdriver

What's Included:



(SFF/4" depth)

QTY 1: SFF (4" depth)
OR Desktop (8" depth)
CPU Holder



(Desktop/8" depth)




QTY 1: 50" Hook
and Loop Strap



QTY 4: 1/4-20
Screws


Step 1:



Fit CPU holder on/around lower part of the inside or
outside of the training table leg.

(Image above shows SFF size.)


Step 2:



Line up holes and insert 1/4-20" screws and secure.

(Image above shows SFF size.)

Step 3:



Use hook and loop strap to secure CPU or unit to CPU
holder by lacing the strap through any of the 10 tie points.

(Image to the left shows SFF size.)

For details about product warranty, please visit www.kendallhoward.com

DISCLAIMER: Kendall Howard LLC. endeavors to make this manual accurate and complete. However, Kendall Howard LLC makes no representations or warranties of any kind, expressed or implied, about whether the use of products contained herein would infringe any rights or the correctness, accuracy or reliability of the information contained herein or that said information covers all details, conditions or variations. The information herein does not provide for every possible contingency in connection with the installation or use of the product(s). The information contained in this document is subject to change without notice or obligation. Kendall Howard LLC assumes no responsibility for the accuracy, completeness or reliability of the information contained in this document. Any reliance placed on the information is therefore strictly at your own risk.